

Specification and Instruction for use

Snitsla Go Bento lunch Box



Pieces:	2 main boxes, 3 lids
Size:	7*4*3.5 inches
Volume:	2*20 fluid ounces
Accessories:	Knife, spoon, fork, divider, <u>small</u> container with <u>lid</u> , 2 rubberbands, insulated lunch bag
Materials:	FDA approved and BPA free plastics PS,PE, PP, ABS, Polyester
BOX / Washing:	Large box in in dishwasher. Lids and small box by hand or in low temperature in <u>dishwasher</u>
BOX / Microwave:	<u>Large</u> box is microwave safe if filled with food or liquid Time in <u>microwave</u> not more than 2 minutes at a time. Control the heat of <u>food</u> . If the box is not filled with food, the box itself will adsorb microwaves and may get damaged.
LIDS:	Lids should be washed by hand and not microwaved as they will get damaged
RUBBERBAND:	Do not place in microwave, dishwasher or freezer
LUNCH BAG:	Insulating. Wash by hand.

